



protegear.io Administration

TripShare
SmartSafety



ProteGear.io → TRIPSHARE : Actions directly on and for the device

TRIP

create LiveTracking Websites with date and data filters

Important: Please choose your visible devices here!

DEVICES

name and activate/suspend devices

Changed	Type	Trigger	Issuer
4.11.2020, 09:44:45	DEACTIVATE	MANUAL	
1.11.2020, 18:49:06	ACTIVATE	auto activation	alive service
3.8.2020, 08:44:00	DEACTIVATE	MANUAL	
31.7.2020, 09:25:06	ACTIVATE	auto activation	alive service
31.7.2020, 08:44:37	DEACTIVATE	MANUAL	

GLOBALMAIL

set globalmail features like SMS, Whitelist/Blacklist

Always drop spam



HANDLER

define actions for specific events of the device, e.g. PRESET-Messages

Important: The link (URL) to the preset basic trip is stored in the "Share LiveTracking SEND-EMAIL" handler. If this trip has been changed or deleted, the link must also be updated here.

ProteGear.io → TRIPSHARE : Possible parameters for TRIPVIEWS:

Open the TripView on the page <https://protegear.io/tripshare/#/trips>



You can pass on the link of the then opened website to your friends and family.

Options in TripView: Map types Satellite, Hybrid, Terrain, Roadmap, Tracking track

GPX Export: Export all or single tracks via GPX or link to other websites via URL (e.g. <https://umap.openstreetmap.de/en/map/new>).
 GPX export must be unlocked/locked under TripShare → EditYourTrips.

For integration into your website as iFrame:

```
<iframe src="https://protegear.io/tripview/....."></iframe>
```

Additional parameters when calling a TripView URL


(at the end of <https://protegear.io/tripview/show?trip=.....>):

Parameter/example	Function
&track=all	shows all tracks since start time of TripView
&track=IMEI1,IMEI2,...	shows only the tracks of the specified IMEI numbers
&info=all	starts the TripView web page with all info pop-ups displayed
&info=IMEI1,IMEI2,...	starts the TripView website with the info popups for the IMEIs
&zoom=6	opens a certain zoom level around a virtual polygon of all last coordinates
&devices=1	display the left devices panel or =0 (default)
&timeline=1	display the global timeline= or =0 (default)
&hidetitle=1	do not show the title, only the menu icon) or =0 (default)
&since=PTxxH	shows past data only for xx hours before the page is called

Difference Last Contact vs. Latest Position

Last Contact shows the actual last connection, even when it had only poor GPS signal (e.g. indoor).

Latest Position is the last valid position signal (because good GPS signal available).



ProteGear.io → SMARTSAFETY : Calls for help even if you can't

SmartSafety is an automatic monitoring & emergency call system for early detection of critical situations.

Reduces rescue response times by up to 90%. With comrade rescue navigation.


SmartSafety makes sure that critical situations do not go unnoticed, even if you can no longer react yourself, e.g. ...

- Drifting (e.g. on the open sea)
- Treeholes (pits in the snow around tree roots)
- Falls of any kind
- unconsciousness e.g. due to fall, heart attack, lack of oxygen
- Allergic shocks
- Avalanches
- Severe injuries
- Crash ... and many more

The possible alarm scenarios, their triggering and termination can be found on the next page.

The DEADMAN is the "ultimate" last safety line, which triggers even if there is no more connection, e.g. because the device has been destroyed, no radio connection can be established or the battery is empty.

For CRASH recognition it is also possible to set the axes to be measured, which are arranged as follows



Special Advise for possible conflicts of scenarios:

The State **PAUSE** can be triggered by:

(during PAUSE all alarms - except manual SOS - are disabled)

- POWER OFF (quickly 3x Button "POWER")
- TRACK-STOP (Long press on Button "TRACK")
- PAUSE (quickly 2x Button "TRACK" → tracking continues, but monitoring starts only after PAUSE-radius has been left)
- NOT-MOVING (Device is completely motionsless for 15 minutes → conflict with Alarm "Motionsless"!)

DEADMAN

To prevent false alarms when device just falls asleep, the option "NOT-MOVING starts PAUSE" (in PROFILE/PAUSE) should be activated

MOTIONLESS

starts an alarm when the device has been motionless for the given time (usually 0.5 – 12.5 minutes)

→ possible conflict when the option "NOT-MOVING starts PAUSE" has been activated, as it will end the Motionless alarm after 15 minutes

→ recommended to disable option "NOT-MOVING starts PAUSE"

ProteGear.io → SMARTSAFETY : Manual and automatic alarm detections, notifications and escalations

FLEET
group tracking devices

PROFILE
tune automatic alarm scenarios
CRASH
MOTIONLESS
ZONE
HALT
HEIGHT
ALTITUDE
ZONE
EXTERNAL
SPEED / VSPEED
DEADMAN

TOUR (ZONES)
set geo-fences for ZONE detections
(SAFE, DANGER, REST)

CONTACTS
Emergency contacts for GEOS RCC

NOTIFICATION
set 1st line alarm recipients for
SMS, Email, Telegram, API
and individual AlarmUp / Down Messages


TRACE
Setup of the **monitoring** based on the definitions Fleet, Tour and Profiles

Trace-Map
Shows current state of each device according to the PROFILE



Define Alarms
enables alerts sent to your selected contacts (notification)

Feedback on Device
shows states like alarms, pause and rest zone directly on the device.



Define Escalation
forwards your alarm to professional rescue facilities (default setting: GEOS RCC)
Automatic alarms are delayed by default


State/Alarm	How State/Alarm goes UP	How to end State/Alarm (DOWN)
POWER ON / OFF	Power On (PAUSE END) / Power Off (PAUSE START)	
REST 	Inside the REST zone (blue zone in TOURS/ZONES), no automatic alarms are triggered.	Leave REST Zone → move to SAFE zone
PAUSE 	1) Appears after Tracking Stop (long press button TRACK) or Power Off. 2) Appears with PAUSE-on-site (2x button TRACK): tracking continues, but: No automatic alarms are triggered in PAUSE state!	1) Start TRACK (long press) or POWER ON 2) Leave PAUSE diameter set in PROFILE
NOT-MOVING	Device motionless for at least 15 min. Triggers a "PAUSE START" in PROFILE default setting	Move the device to wake up → Pause ends
BATTERY 	Battery charge below 25%	Charge the device
SOS 	Manual SOS call: Press quickly 3x 	CANCEL-SOS: Press quickly 3x 

Automatic Alarm Detections (   if "Feedback on device" is active)

HALT	Moving less than x meters within y minutes ¹	<p>Press quickly 3x  to CANCEL the alarm (→ sends „I am fine“-Message to Notifications)</p> <p>If automatic alarm scenario is still upheld (e.g. you are still in DANGER-ZONE) the alarm is triggered again delayed after x minutes.¹ alternative: Pause the tracking (2x TRACK)</p>
MOTIONLESS	Completely motionless since x minutes ¹	
HEIGHT	x meters above ground (AGL) exceeded / below / inside ¹	
ALTITUDE	x meters above sea level (AMSL) exceeded / below / inside ¹	
ZONE	Inside any DANGER zone (red zone in TOURS/ZONES)	
EXTERNAL	External sensor has been triggered (e.g. airbag via Bluetooth)	
SPEED / VSPEED	Horizontal or vertical speed exceeded or fallen below	
CRASH	Shock above x g-force and eventually subsequent standstill within y minutes and z meters ¹	
DEADMAN (active)	Absence of a specified manual action on the device (e.g. preset-message) since x sec ¹ .	
DEADMAN (passive)	A) "Only Outdoor": Bad GPS reception triggers alarm after x sec. ¹ even if connected B) "Indoor + Outdoor": Absence of any regular tracking since x sec. ¹ triggers alarm This is the ultimate state when your device is „offline“ for whatever reason (destroyed, battery empty, no connectivity)	


¹⁾ The distances or times replaced above with x, y, z can be set individually in menu PROFILE. Also time slots can be limited for each scenario.

Important to know:
All actions on the device (POWER OFF / PAUSE / Automatic Alarm) must be confirmed by the server before they are visible on the device. Therefore some time may pass between action and reaction, especially in satellite mode.



SmartSafety: Example for TOURS / ZONES (Geofences)

BaseLayer **DANGER**



REST ZONE
disables all alarms
except SOS and DEADMAN2

SAFE ZONE
deactivates ZONE alarm

DANGER ZONE
triggers ZONE alarm

BaseLayer **DANGER**

